

# Using Your ViewSonic® VPC100 Webcam

To begin using the VPC100's integrated webcam for photo and video captures, follow the instructions below:


## Photo capture:

(see image on the right)

1. Click on the Start button
2. Select Programs
3. Select Accessories
4. Select Scanner and Camera Wizard
5. Follow the instruction in the Scanner and Camera Wizard.

## Video Capture and Edit:

1. Click on the Start button
2. Select Programs
3. Select Windows Movie Maker
4. Begin capturing video.



To download free software for more advanced video recording or live video conferencing visit one of the web sites below:

Skype: [www.skype.com/welcomeback](http://www.skype.com/welcomeback)

Windows Live Messenger: [www.download.live.com](http://www.download.live.com)

For technical questions regarding your VPC100, please visit [www.ViewSonic.com/support](http://www.ViewSonic.com/support) or call (888) 572-9237 or outside the United States call (909) 444-8801.